

# VisiCom 4000 Programmable Feature Summary

Menu #	Feature	Description	Display icons	Available options	Default setting	Shared settings approach		Teach button combination	* Learn button combination
						Automatic or Manual	Single or Group		
1	Button press tone	Selects whether a short tone is sounded as each button is pressed	↑	Enable tone	↑	M	S	MEET AT, CLEAR	-
			↓	Disable tone					
2	Communications Mode	Communications channel to use	0 1 2	0=Radio only 1=Hardwire 2=Bridge mode	0	M	S	MEET AT, CLEAR	-
3	Auto-clear message (with badge)	If badges are in use, selects whether badge presence causes automatic check-in	↑	Auto clear	↑	M	G	CLEAR, NEXT, top 4	CLEAR, NEXT, bottom 4
			↓	No auto clear					
4	Room numbers or room letters	Select room codes from <b>1 to 26</b> , or <b>A to Z</b>	↑	Room numbers	↑	A	S	-	-
			↓	Room letters					
5	Master chime on/off	Turns chimes on or off	↑	Chimes on	↑	M	S	MEET AT, CLEAR	-
			↓	Chimes off					
6	Master chime setting	Choose chime setting that applies to <b>all</b> person codes	#	Numbers 1 to 8, or 0 (silent)	4	M	G	CLEAR, NEXT, top 4	CLEAR, NEXT, bottom 4
7	Personal chimes settings	Choose individual chime settings that apply to each person code	→	Numbers 1 to 8, or 0 (silent)	4	M	G	CLEAR, NEXT, top 4	CLEAR, NEXT, bottom 4
8	Rechiming (2-press) on/off	Repeat chime tone each time a priority message is displayed	↑	Rechime on	↑	M	S	MEET AT, CLEAR	-
			↓	Rechime off					
9	Long-key-press setting	Control function that applies when a keyboard key is held for 2 seconds	0 1 2	0=Chime restriction 1=Total restriction 2=Manual login	2	M	G	CLEAR, NEXT, top 4	CLEAR, NEXT, bottom 4
10	Message crawl on/off (only with total restriction)	In total-restriction mode, message scrolling control	↑	Show all messages	↑	M	S	MEET AT, CLEAR	-
			↓	Show earliest message					
11	Sort messages by <b>person</b> on/off	Sort by provider, or display in as-entered sequence	↑	Sort by provider	↑	M	S	MEET AT, CLEAR	-
			↓	Display as received					
12	Badge sleep setting	If badges are in use, controls timing of verification	#	Numbers 1 to 10 1=most rapid 10=least rapid	5	A	S	-	-
13	Message diagnostics on/off	Shows a room id with an arrow on any missed messages	↑	Enable diagnostic	↓	M	S	MEET AT, CLEAR	-
			↓	Disable diagnostic					
14	Top row → program initials	Assign any character from A to Z to each top-row button	↑	Ph, Pt, or Fd and letters A to Z (or numbers 1 to 26)	<b>A to H</b>	A	S	-	-
15	Bottom row → program room numbers	Assign room numbers to bottom row buttons	↓	Ph, Pt, or Fd and numbers 1 to 26 (or letters A to Z)	<b>1 to 8</b>	M	S	MEET AT, CLEAR	-
16	Program color assignments	Assign individuals various LED colors	↑	Assign colors 1 to 8, or 0	↑	A	S	-	-
17	*Accept system-wide program settings	Set a unit in isolation mode and disregard shared settings	↑	Accept only automatic settings	↓	-	-	-	-
			↓	Accept all settings					
18	Show undisplayed messages using the right-most LED	Indicate by lighting the right-most LED there are undisplayed messages	↑	Use right-most LED	↓	M	S	MEET AT, CLEAR	-
			↓	Right-most LED normal					

\* These settings are not applicable to the system "Coordinator" unit