VisiCom 3000 Programmable Feature Summary

Menu Option Number STD	Menu Option Number PRO	Feature	Description	Display Icons	Available Settings	Default Setting
1	1	Button Press Tone	Selects whether a short tone is sounded as each button is pressed	↑	Enable tone	↑
				↓	Disable tone	
2	2	Communications Mode	Communications channel to be used		0=Radio only 1=Hardwire 2=Bridge mode	0
3	3	Auto Clear Message w/Badge	Where badges are in use, selects whether messages clear as room is entered	↑	Auto clear	↑
				↓	No auto clear	
4		Numeric Room Codes	Select room codes from **A to Z** or **1 to 26** (Standard units only)	↑	Room=number	↓
				↓	Room=letter	
	4	Reply Rechime Mode	Rechime each time a "replied-to" message is redisplayed (Pro only)	↑	Rechime on	↓
				↓	Rechime off	
5	5	System Chime Enable	Turns chimes on or off	↑	Chimes on	↑
				↓	Chimes off	
6	6	System Chimes Selection	Choose chime setting that applies to all person codes		Numbers 1 to 8, 0, or V *	1
7	7	Personal Chime Selections	Choose individual chime settings that apply to each person code		Numbers 1 to 8, 0	ALL: 4
8	8	Priority Rechime Enable	Repeat chime tone each time a priority message is displayed	↑	Rechime on	↑
				↓	Rechime off	
9	9	Long Keypress Mode	Control function that applies when a keyboard key is held for 2 seconds		0=Chime restr 1=Total restr 2=Manual login	2
10	10	Restricted Message Scrolling	In restricted mode, message scrolling control	↑	Show all msgs	↑
				↓	Show earliest	
11	11	Message Sort Mode	Sort messages display sequence	↑	Sort by staff #	↑
				↓	Display as recvd	
12	12	Badge Sleep Setting	If badges are in use, controls periodicy of verification		Numbers 1 to 10	5
13	13	Missed Message	Shows a moving arrow & room ID on missed msgs	↑	Enable display	↓
				↓	Disable display	
14		Bottom Row Function	Cancel messages or page to a remote location	↑	Remote paging	↓
				↓	Cancel mode	

↑ VisiCom Pro menu option number
↑ VisiCom Transceiver, Reception Transceiver and Extended Transceiver menu option number

* **NOTE:**
0=No chime
V=Various chimes from Menu 7